



Figure 7.10 An instruction that can be inserted to add delay processing to wait for the ALU to complete an operation. Timing and delay are crucial aspects of horizontal microcode.